



# CP

## BASIN-TYPE VEGETABLE CHOPPER MACHINE



# CP30

**Control Panel**



# CP30

Chopping bowl



# CP30

Knife group



# CP30

Sensor switch



# CP30

## Effect Display

